

Meadow Creek® TS120

Overall Dimensions: 72"H x 150"L x 57"W

Top Grate Dimensions: 20" x 41¾"

Bottom Grate Dimensions: 22" x 41¾"


Warming Box Grate Dimensions: 11½" x 17½"

Product Details: Metal Thickness On Tank 3/16" Plate • Metal Thickness On Firebox ¼" Plate

Net Weight: 1140 lbs.

Shipping Weight: Same, Unless Skidding Required,
Then Approx. 1400 lbs.

Standard	Standard Options	Custom Options
Stainless Steel Slide Out Grates	Trim Package	Fire Extinguisher Mount
Reverse Flow Draft	Extra Shelves In Warmer	Mount For Spare Tire
Positive Lock Latches	Extra Shelves In Smoker	Add Any Meadow Creek® Cooker To Trailer
Ash Slide Out Pan	Spare Tire	
Charcoal Grate In Fire Box	Charcoal Grilling Pan	Stainless Steel Shelves
Built In Water Pan	Live Smoke In Warmer	S. S. Table Top To Fit Over Wood Box
Ball Valve Drain	Add BBQ26S or BBQ42	
All Stainless Steel Handles	Hot & Cold Running Water with 3-Bay Sink	
Stay Cool Handles on Slide Vents		
Thermometer on Smoker & Warming Box	Charcoal Basket	
	Slide Out Charcoal Basket	
2 Shelves On Outside	Trailer Brakes	
13" Highway Wheels		
2" Ball Hitch		
Wheel Jack		
Warming Box w/ 3 Shelves		
Safety Chains		
Rubber Torque Heavy Duty Axle		
E.Z. Lube Bearing		
Trailer Lights, 4 Prong Flat		
Wood Box		
Heat Baffles On Fire Box To Protect Wheels		



Recommended with the:

TS120 - For Smoking - we recommend using non petroleum based starters. Residue in the smoke from these starters can contaminate the cooking box with the potential to effect the flavor of the meat. The use of a torch or paper and kindling is most effective. Use approximately 25-30 lbs. of charcoal in fire box to get started. Once meat is placed in smoker, you can add wood in fire box for smoking. You can continue to use wood or charcoal (your choice). Add wood or charcoal as needed to maintain temperature where you want it. Optional charcoal basket holds approximately 40 lbs. of charcoal briquettes and ensures efficient, even temperatures.

For Grilling - remove bottom grate from smoker and slide in optional charcoal pan. Put in you desired amount of charcoal and slide top grate above charcoal pan.



TS120

